

How to fit blinds in a Robinsons Ratcliffe / Rushmoor



The best way to attach the blinds at the top of the roof is to clamp the tabs in between the spandrel and the glazing bar. Or when you have an A-frame, you can clamp the tabs in between the glazing bar and the A-frame channel in a similar way.

Position the blinds a little down from the top so that the tabs are just above the bolt going through the spandrel.

You may have to undo one side of the spandrel to make it easier to get the blind in



Left: To attach the hooks on a standard glazing bar, simply remove the nut from the spandrel and attach the hook with the same nut.

Right: where you have an A-frame you can use an L-shaped bracket D174 to attach the bracket (using the existing bolt which goes through the A-frame channel and plate)



There is no official blind pulling pole sold, however its easy to make one by using a screw-in hook on the end of a broom stale. Please note that a hole will need to be drilled into the blind handle to enable the hook to engage.

