

# ELITE 2.7kW FAN HEATER

## USER INSTRUCTIONS



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children of less than 3 years should be kept away from the appliance unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch ON/OFF the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

It is recommended that the user does not perform mechanical or electrical maintenance on this appliance. if in doubt contact the manufacturer.

If the supply cord is damaged. it must only be replaced by the manufacturer in order to avoid hazard.

### **INSTALLATION**

**The heater must not be located immediately below a socket outlet.**

When the feet and handle are attached the appliance must not be moved during operation. If the chains are used to hang the appliance it must be installed 1.8mtrs from the floor. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.

Hang your new ELITE with the chains provided ( The hooks may need opening out a little prior to there first use ) or stand it on the floor. Choosing the right position is important to ensure maximum benefit from the air movement created and the heat produced.

All greenhouses are different so no firm recommendations can be made.

It is most important however to ensure that the air can circulate properly. Clearance from any surface must be no less than 150mm.

### **OPERATION**

Details of the four position rotary switch as below:

- |            |  |
|------------|--|
| Position 1 | 'OFF'  |
| Position 2 | Fan only 'ON' (for summer use)                 |
| Position 3 | Fan and Half heat controlled by the thermostat |
| Position 4 | Fan and Full heat controlled by the thermostat |

The circulating fan in your ELITE is controlled by the thermostat meaning the fan will turn on and off with the heating elements giving increased economy.

The thermostat probe is the copper phial sited on the side of the unit. Be sure to protect this from direct sunlight (kitchen foil can be used to form a simple shield against heat from the sun). The thermostat cannot be moved from the side of the electrical control box.

## **SAFETY**

### **WARNING - IN ORDER TO AVOID OVER HEATING DO NOT COVER THE HEATER.**

Although all of our products are designed for use in a greenhouse environment and are made to very high standards, it is essential that all users are conscious of the possible dangers of using any electrical appliance in damp conditions such as those that prevail in greenhouses. It is advisable to turn off, unplug and remove the appliance when watering in the greenhouse. If the appliance does get wet it must be thoroughly dried out before further use.

Allow the appliance to cool before cleaning.

If the appliance is run continuously it is recommended that it is monitored or checked regularly or at least every 8 hours or so.

### **CAUTION - SOME PARTS OF THIS PRODUCT CAN BECOME VERY HOT AND CAUSE BURNS. PARTICULAR ATTENTION HAS TO BE GIVEN WHERE CHILDREN AND VULNERABLE PEOPLE ARE PRESENT.**

**It is strongly recommended that each electrical appliance is used with an R.C.D (Residual Current Device) suitable for use with portable electrical equipment outdoors.**

***It may be necessary to run the heater on FULL for 10 minutes without an RCD to burn the elements in on the first use.***

## **CONTENTS**

2 X 30cm LONG CHAINS  
2 X LEGS  
4 X SCREWS

## **FIXING THE CHAINS**

CONTACT YOUR GREENHOUSE MANUFACTURER FOR THE BEST WAY TO FIX THE CHAINS TO THE STRUCTURE. THEN ATTACH THE CHAIN TO THE HOLES PROVIDED ON THE TOP OF THE APPLIANCE AS INDICATED.

## **TO FIX LEGS**

REMOVE THE LEGS AND SCREWS FROM BAG. USING A POZI SCREWDRIVER FIX THE LEGS TO UNDERSIDE OF THE STAINLESS STEEL BODY.



**Made in England by: Kirklees Developments Ltd**

Mill 2, St Pegs Mill, Thornhill Beck Lane, Brighouse,  
West Yorks, HD6 4AH Tel: + 44 1484 401134

Web: [www.kdev.co.uk](http://www.kdev.co.uk) Email: [enquiries@kdev.co.uk](mailto:enquiries@kdev.co.uk)